

# Fixing Instructions

## Installation Procedure

1. Check size of rooflight and size of external kerb to make sure that the rooflight will fit down over the kerb.
2. Check that the kerb is flat and level and in one continuous plane (this is most important as this could affect drainage).
3. Position one or two beads of butyl/tape to the underside of the rooflight frame, dependent on the size of the rooflight (do one bead, then see if there is enough room left for a second bead).
4. Position the rooflight onto the top of the kerb, ensuring the butyl/tape is in contact with the kerb around the full perimeter.
5. Using the fixing screws supplied, fix the frame to the kerb. This should be done horizontally through the fixing holes pre-drilled in the lower part of the perimeter frame.
6. **PLEASE NOTE:** Once the rooflight has been installed, all the protection film should be removed on the day of installation. The protection film, which has no UV protection, will become brittle and difficult to remove over time and may damage the paint if left for a prolonged period.

